



OWNERS MANUAL



SINGLE CAPTAIN SEAT

HOW TO SWIVEL YOUR SEAT



- . Start with making sure that the seat is slightly forwards and in an upright position.

~

Make sure that the seat is raised using the lever between the door and the base of the seat so that the plastic covers do not catch on the swivel mechanism.

~

With your right hand push the red swivel release lever forwards and keep pressure, with your left hand grab the right hand of the seats and give it a solid pull. If you find it easier you can push the left side of the base instead of pulling the right.

~

Reverse to put away and make sure it clicks back into position

DOUBLE SEAT



HOW TO SWIVEL YOUR SEAT



Unwind, lift up into lock position the 4 locking bolts out so that the seat can move freely on its pivot point.

~

Make sure that the driver's seat is in the upright position, slide as far back as possible with the armrest raised up.

~

Then take the bench seat and slide the righthand side forwards and up towards the gear stick.

~

Then start to turn the seat around. You will use a light bit of force to get the seat base past the hand brake and then past the door pillar.

~

Bring the seat into position and drop the two locking bolts back down so that the seat doesn't move.

~

Reverse to put away.

POP TOP ROOF

HOW TO RAISE & PUT DOWN YOUR ROOF



To raise the roof to undo the two straps fully.

~

Once straps are completely undone push the roof up. The gas struts will push the roof into its fully open position since you get it moving.

~

To open the scenic tent pull down on the straps a little to release the pressure from the gas struts. This will then allow you to unzip the bottom of the scenic tent. Once unzipped you fold the tent back and use the poppers to clip the canvas into its upright position.

~

To put away the scenic tent pull down on the straps to release the pressure on the gas struts and then zip back up.

~

To put the top back down pull it down 80% of the way until the roof is being held down under its own weight. Then tuck in the canvas of the tent so non are sticking out. Feed the straps back through the loops and pass the end of the strap flat from the back to the front of the strap buckle. Pull down and tight making sure the outside rubber has a tight seal.



BATTERY

HOW TO USE YOUR BATTERIES



Battery isolator & DCD/DC Charger

The isolator should always be in the on position (it will either be on 1 or 2). We recommend turning it off if the battery is already full.

The Isolator separates your leisure battery from the main van battery for maintenance and safety purposes.

Victron Energy DC/DC charger will charge the battery whilst the engine is running via the Alternator.



1. Diesel heater
2. Fridge
3. USB 12v plugs
4. Lights and water

Battery test indicator & Fuses

Press the button, it is traffic light system to show you how much charge is in the battery based on 0-100%.



12 volt fridge switch

This switch turns the fridge on, if the light is on the fridge is running on 12volts battery, if the light off it is off or on the 230v hook up if plugged in.

BATTERY

HOW TO USE YOUR BATTERIES



230v Hookup

Pop bonnet and plug it in.

~

Blue lever is to release the plug when taking out.

~

When it is plugged in drape cable past lights and close bonnet to first catch.

~

It will indicate that it is open on the dash board so you hopefully wont be driving off without seeing that!

~

Make sure you switch the fridge over.

~

You have 2 circuit breakers located in the cupboard. They should always be on. The 16amp RCBO is the main supply and should always be on. The secondary MCB is for the smart charger and also should always be left on.



BATTERY



HOW TO USE YOUR BATTERIES

Small charger and leisure battery

The smart charger will automatically charge the leisure battery once you have hooked up to the mains on the 230v. it will turn itself on and off when needed and keep the battery topped up.

~

The second way of charging is when the engine is running via a split charge.

~

Two modes of charging the battery.

~

To go from 0-100% charge:

- 2amp smart charge a full charge = 24-30 hr
- 5amp smart charge a full charge = 8-10 hr
- 10amp smart charge 4-6 hrs.
- Engine alternator charge 4-6hrs



GAS BOTTLE



HOW TO USE YOUR GAS BOTTLE



Remove the cover with quarter-turn catches, pull the retainer strap loose, remove the bottle.

~

To remove the hose off of the bottle that is a reverse thread. To remove the regulator off the bottle you just unscrew it.

~

To fit a new bottle, screw on the regulator, screw on the hose (reverse thread) and make sure they are screwed tight.

~

Make sure that the tap on top of the regulator is turned off when not in use (ie travelling).

~

When changing the bottle the hob will take a few clicks to pull through the new gas.



WATER

HOW TO USE YOUR WATER



Under the sink of the van we have a fresh water tank with sump pump. To remove the bottle you unscrew the red lid. The pump hoses and pump lift out.

~

We have a waste pipe and the campsite etiquette is to have a bucket to catch the dishwater.



DIESEL HEATER

HOW TO USE YOUR DIESEL HEATER



The heater is on a fuse. It has an LCD display. See manual provided for the full instructions. It comes with a remote. It is into the diesel tank main and this will not be possible to use if $\frac{1}{4}$ tank.

~

Full instruction manual will be provided.



ROCK N ROLL BED

HOW TO USE YOUR ROCK N ROLL BED



To release from seat into bed you slide the lever to release the bed lock

~

Then take hold of the metal bed frame, put pressure on headrests to lock in once the bed is 90% down.

~

Then to put back to seat pull the release pin and keep pressure on the headrest to ensure the mechanism unlocks and just push back into place.

TIPS

SAVING BATTERY POWER



As you will unlikely be using the Diesel heater during the summer you can take fuse number 4 for the diesel heater out and store it somewhere safe. This will mean that the LED display for the diesel heater is not on. It is only a small drain, but every little helps.

~

If you run the fridge at setting 2 you will have the optimum balance between keeping everything cool and battery usage.

EXTRAS

Spare wheel is under the van at the rear and jack etc and lock nut are under the passenger seat.

Email us on tom@bearwoodcampers.co.uk or call/message us on 07741577402

